




B 001

ELECTRONIC BOARD BJ



B 002

ELUCIDATE BOARD (display)



B 003

COIN MECH "WH"



B 003a

COIN MECH "C-120"



B 004

FRONT PANEL FOR COIN MECH "WH"



B 004a

FRONT PANEL FOR COIN MECH "C-120"



B 005

BUTTON

(start, speed, strenght)




B 005a

PUSH BUTTON WITH THE MICROSWITCH



B 006

TOP GLASS



B 007

MIDDLE GLASS



B 008

BOTTOM GLASS



B 009

COMPLETE PUNCH BALL

(1 leather, 1 bladder, 1 screw with the rubber, 1 clot)



B 009a

COMPLETE PUNCH BALL (used I category)



B 009b

COMPLETE PUNCH BALL (used II category)



B 009c

COMPLETE PUNCH BALL (used III category)



B 010

BLADDER



B 011

LEATHER FOR THE PUNCH BALL(NEW)



B 011a

LEATHER FOR THE PUNCH BALL (used I category)



B 011b

LEATHER FOR THE PUNCH BALL (used II category)



B 011c

LEATHER FOR THE PUNCH BALL (used III category)



B 012

CLOTH (between ballon and leather)



B 013

PROTECTION FOR THE PUNCH BALL



B 013a

PROTECTION FOR THE PUNCH BALL (new)



B 014

SCREW WITH THE RUBBER



B 015

METAL CONSTRUCTION TO HOLD PUNCH BALL



B 015a

METAL CONSTRUCTION TO HOLD PUNCH BALL
(complete)




B 016

ELECTROMAGNET



B 017

CABLES (inside joining from elucidate board to light bulbs left- 10 - bulbs)



B 017a

CABLES (inside joining from elucidate board to light bulbs right 6-bulbs)



B 018

CABLES (inside joining from electronic board to electromagnet)



B 019

CABLES (inside joining from coin mech to electronic board)



B 020

CABLES (inside joining from elucidate board to electronic board)



B 021

POWER CABLE



B 022

POWER SOCKET WITH HORIZONTAL SWITCH



B 022a

POWER SOCKET WITH VERTICAL SWITCH



B 023

TRANSFORMER




B 024

PLASTIC (between elucidate board and middle glass)



B 025

COVER FOR TOP OF THE BOXER




B 026

LIGHTS FOR COVER FOR TOP OF THE BOXER



B 027

SPOT LIGHT FRAME



B 027a

METAL HOLDER FOR THE SPOT LIGHT



B 028

LIGHT BULB



B 029

BACK DOORS (top)




B 030

BACK DOORS (bottom)



B 031

WHELL



B 032

BUNERS FOR BOXER



B 033

RUBBER TO STOP THE BALL (after punch)




B 034

PILLOW NEXT TO RUBBER



B 035

SPEAKER



B 036

SENSOR



B 037

BULBS#286 (small) - 10 units



B 038

BULBS#1116 (big) - 10 units



B 039

LAMPHOLDER FOR BULBS#1116 (big) - 10 units



B 040

LAMPHOLDER FOR BULBS#286 (small) - 10 units




B 053

CORNERS OF THE BOXER



B 054

LOCK



B 055

ALUMINIUM BASE PLATE




B 056

TICKER DISPENSER



B 057

BANKNOTE ACCEPTOR




B 058

FRONT PANEL FOR BANKNOTE ACCEPTOR WITH THE FRAME



B 059

COVER FOF BANKNOTE ACCEPTOR



B 060

FRAME FOR BANKNOTE ACCEPTOR



B 061

LACE FOR LEATHER FOR PUNCH BALL



B 062

CABLE (beetwen banknote acceptor and coin mech)




B 063

CABLE (beetwen electronic board and halogens)



B 080

RUBBER FOR COIN MECH




B 041

CABLE (between display and light for the top glass)



B 042

CABLE (between display and speed and strenght buttons)



B 043

CABLE (between the display and start button, speaker)



B 044

TIE



B 045

FUSES X 10 UNITS




B 046

HALOGEN COVER



B 047

MONEY BOX



B 048

RUBBER FOR TRANSFORMER



B 049

HAMMER (between metal construction and electromagnet)



B 050

SPRING FOR THE METAL CONSTRUCTION



B 051

SLEEVE (for the metal construction next to the spring)



B 052

RUBER TO STOP THE MECHANIZM